

LinkPoint CARDnet EBT Quick Reference Card



FUNCTION	DISPLAY MESSAGE	OPERATOR ACTION
EBT CASH BENEFIT PURCHASE	1. SWIPE CARD FOR SALE	1. Press [ATM/DEBIT] .
	2. EBT DEBIT	2. Press the left [▲] key.
	3. FOOD CASH VCHR	3. Press the middle [▲] key.
	4. SALE BAL	4. Press the left [▲] key.
	5. CB SALE ENTER ACCOUNT #	5. Swipe the card through the card reader.
	6. FUEL AMNT*	6. Key in the fuel amount and press [ENTER] or press [ENTER] to bypass.
	7. FUEL GRADE* 1=NNNNNNNN	7. Press the correct key from [1] to [5] to choose the proper fuel grade.
	8. MISC AMNT*	8. Key in the amount of the non fuel transaction item and press [ENTER] or press [ENTER] to bypass.
	9. EB CB SALE ENTER BASE AMOUNT	9. Key in the amount of the transaction and press [ENTER] .
	10. EB CB CUST ENTERS CASHBACK	10. Please wait...

PIN PAD DISPLAY	PIN PAD ACTION
11. CASH BACK AMOUNT	11. Customer keys in the cash back amount and presses [ENTER] on the PIN pad or presses [ENTER] on the PIN pad to bypass cash back option. To clear and re-enter the cash back amount, press [CLEAR] .
12. TOTAL \$XX.XX IS THIS CORRECT?	12. Press [ENTER] for "Yes" or press [BACK SPACE] for "No".
13. WAITING FOR PIN	13. Customer enter PIN on PIN pad.

PIN PAD DISPLAY	PIN PAD ACTION
14. TOTAL \$XX.XX ENTER PIN	14. Customer keys in their PIN and then presses [ENTER] on the PIN pad.
15. DIALING...CONNECTED	15. Please wait...
16. EB CB SALE AP XXX SEQ XXXX	16. Please wait for the merchant receipt to print.
17. TEAR NOW, PRESS ENTER	17. Press [ENTER] to print customer receipt.

*NOTE: These prompts will appear only if the petroluem option is enabled.

FUNCTION	DISPLAY MESSAGE	OPERATOR ACTION
EBT CASH BENEFIT BALANCE INQUIRY	1. SWIPE CARD FOR SALE	1. Press [ATM/DEBIT] .
	2. EBT DEBIT	2. Press the left [▲] key.
	3. FOOD CASH VCHR	3. Press the middle [▲] key.
	4. SALE BAL	4. Press the right [▲] key.
	5. CB INQUIRY ENTER ACCOUNT #	5. Swipe the card through the card reader.
	6. WAITING FOR PIN	6. Please wait...

PIN PAD DISPLAY	PIN PAD ACTION
7. AMOUNT \$XX.XX... ...ENTER KEY	7. Customer keys in their PIN and then presses [ENTER] on the PIN pad.
8. DIALING...CONNECTED	8. Please wait...
9. INQUIRY AP XXX	9. Please wait for merchant receipt to print.
10. TEAR NOW, PRESS ENTER	10. Press [ENTER] to print customer receipt.

FUNCTION	DISPLAY MESSAGE	OPERATOR ACTION
EBT FOOD STAMP PURCHASE	1. SWIPE CARD FOR SALE	1. Press [ATM/DEBIT] .
	2. EBT DEBIT	2. Press the left [▲] key.
	3. FOOD CASH VCHR	3. Press the left [▲] key.
	4. SALE RET BAL	4. Press the left [▲] key.
	5. FS SALE ENTER ACCOUNT #	5. Swipe the card through the card reader.
	6. EB FS SALE ENTER TOTAL AMOUNT	6. Key in the total amount and press [ENTER] .
	7. TOTAL \$XX.XX IS THIS CORRECT?	7. Press [ENTER] for "Yes" or press [BACK SPACE] for "No".
	8. EB FS SALE WAITING FOR PIN	8. Please wait...

PIN PAD DISPLAY	PIN PAD ACTION
9. AMOUNT \$XX.XX... ...ENTER KEY	9. Customer keys in their PIN and then presses [ENTER] on the PIN pad.
10. DIALING...CONNECTED	10. Please wait...
11. EB FS SALE AP XXX SEQ XXXX	11. Please wait for merchant receipt to print.
12. TEAR NOW, PRESS ENTER	12. Press [ENTER] to print customer receipt.

FUNCTION	DISPLAY MESSAGE	OPERATOR ACTION
EBT FOOD STAMP RETURN	1. SWIPE CARD FOR SALE	1. Press [ATM/DEBIT].
	2. EBT DEBIT	2. Press the left [▲] key.
	3. FOOD CASH VCHR	3. Press the left [▲] key.
	4. SALE RET BAL	4. Press the middle [▲] key.
	5. FS RETURN ENTER ACCOUNT #	5. Swipe the card through the card reader.
	6. EB FS RETURN AMOUNT	6. Key in the return amount and press [ENTER].
	7. TOTAL \$XX.XX IS THIS CORRECT?	7. Press [ENTER] for "Yes" or press [BACK SPACE] for "No".
	8. EB FS SALE WAITING FOR PIN	8. Please wait...

PIN PAD DISPLAY	PIN PAD ACTION
-----------------	----------------

9. AMOUNT \$XX.XX... ...ENTER KEY	9. Customer keys in their PIN and then presses [ENTER] on the PIN pad.
10. DIALING...CONNECTED	10. Please wait...
11. EB FS RETURN AP XXX SEQ XXXX	11. Please wait for merchant receipt to print.
12. TEAR NOW, PRESS ENTER	12. Press [ENTER] to print customer receipt.

FUNCTION	DISPLAY MESSAGE	OPERATOR ACTION
EBT FOOD STAMP BALANCE INQUIRY	1. SWIPE CARD FOR SALE	1. Press [ATM/DEBIT].
	2. EBT DEBIT	2. Press the left [▲] key.
	3. FOOD CASH VCHR	3. Press the left [▲] key.
	4. SALE RET BAL	4. Press the right [▲] key.
	5. FS INQUIRY ENTER ACCOUNT #	5. Swipe the card through the card reader.
	6. WAITING FOR PIN	6. Please wait...

PIN PAD DISPLAY	PIN PAD ACTION
-----------------	----------------

7. AMOUNT \$XX.XX... ...ENTER KEY	7. Customer keys in their PIN and then presses [ENTER] on the PIN pad.
8. DIALING...CONNECTED	8. Please wait...
9. INQUIRY AP XXX	9. Please wait for merchant receipt to print.
10. TEAR NOW, PRESS ENTER	10. Press [ENTER] to print customer receipt.

FUNCTION	DISPLAY MESSAGE	OPERATOR ACTION
EBT VOUCHER FORCE PURCHASE	1. SWIPE CARD FOR SALE	1. Press [ATM/DEBIT].
	2. EBT DEBIT	2. Press the left [▲] key.
	3. FOOD CASH VCHR	3. Press the right [▲] key.
	4. SALE RET	4. Press the left [▲] key.
	5. VCLR SALE VOUCHER NUMBER	5. Key in the voucher number.
	6. VCLR SALE ENTER ACCOUNT #	6. Key in the EBT card number, press [ENTER].
	7. EB VCLR SALE ENTER TOTAL AMNT	7. Key in the sale amount and press [ENTER].
	8. TOTAL \$XX.XX IS THIS CORRECT?	8. Press [ENTER] for "Yes" or press [BACK SPACE] for "No".
	9. EB VCLR SALE AUTH CODE	9. Key in the auth code and press [ENTER].
	10. DIALING...CONNECTED	10. Please wait...
	11. EB VCLR SALE AP XXX SEQ XXXX	11. Please wait for merchant receipt to print.
	12. TEAR NOW, PRESS ENTER	12. Press [ENTER] to print customer receipt.

FUNCTION	DISPLAY MESSAGE	OPERATOR ACTION
EBT VOUCHER RETURN	1. SWIPE CARD FOR SALE	1. Press [ATM/DEBIT].
	2. EBT DEBIT	2. Press the left [▲] key.
	3. FOOD CASH VCHR	3. Press the right [▲] key.
	4. SALE RET	4. Press the middle [▲] key.
	5. EB VCLR RETURN VOUCHER NUM	5. Key in the voucher number.
	6. VCLR RETURN ENTER ACCOUNT #	6. Key in the EBT card number, press [ENTER].
	7. EB VCLR RETURN AMOUNT	7. Key in the sale amount and press [ENTER].
	8. TOTAL \$XX.XX IS THIS CORRECT?	8. Press [ENTER] for "Yes" or press [BACK SPACE] for "No".
	9. EB VCLR RETURN AUTH CODE	9. Key in the auth code and press [ENTER].
	10. DIALING...CONNECTED	10. Please wait...
	11. EB VCLR RET AP XXX SEQ XXXX	11. Please wait for merchant receipt to print.
	12. TEAR NOW, PRESS ENTER	12. Press [ENTER] to print customer receipt.

FUNCTION	DISPLAY MESSAGE	OPERATOR ACTION
CLOSE BATCH	1. SWIPE CARD FOR SALE	1. Press [CLOSE].
	2. SCANNING TRANS...	2. Please wait...
	3. PRINT REPORT YES NO	3. Either press the left [▲] key to print the Batch Summary Report or the right [▲] key not to print the report.
	4. DIALING...	4. Please wait...
	5. SETTLEMENT COMPLETE XXXXXXXXXXXX	5. Please wait for Batch Close Report to print.