

LinkPoint CARDnet Petroleum Quick Reference Card



FUNCTION	DISPLAY MESSAGE	OPERATOR ACTION
SALE	1. SWIPE CARD FOR SALE	1. Swipe card.
	2. CARD TYPE SALE CARD TYPE TRANSACTION?	2. Press [ENTER] .
	3. CARD TYPE SALE ENTER LAST 4 DIGITS	3. Key in the last four digits of the credit card number and press [ENTER] .
	4. XXXXXXXXXXXXX IS CARD # CORRECT?	4. If the displayed card number is correct, press [ENTER] , if not press [BACK SPACE] .
	5. CARD TYPE SALE FUEL AMNT	5. Key in the fuel amount and press [ENTER] or press [ENTER] to bypass.
	6. CARD TYPE SALE CONFIRM AMOUNT	6. Key in fuel amount again and press [ENTER] .
	7. FUEL GRADE 1=NNNNNNNN	7. Press the correct key from [1] to [5] to choose the proper fuel grade.
	8. CARD TYPE SALE MISC AMNT	8. Key in amount of the non fuel transaction and press [ENTER] or press [ENTER] to bypass.
	9. TOTAL \$XX.XX IS THIS CORRECT?	9. Press [ENTER] for "Yes" or press [BACK SPACE] for "No".
	10. WAITING...RECEIVING	10. Please wait...
	11. CARD TYPE SALE AP XXXXXX SEQ XXXX	11. Please wait for the merchant receipt to print.
	12. TEAR NOW, PRESS ENTER	12. Press [ENTER] to print customer receipt.

FUNCTION	DISPLAY MESSAGE	OPERATOR ACTION
ATM/DEBIT CARD SALE (OPTIONAL- PIN PAD REQUIRED)	1. SWIPE CARD FOR SALE	1. Press [ATM/DEBIT] .
	2. EBT DEBIT	2. Press the right [▲] key.
	3. ENTER ACCOUNT #	3. Swipe card.
	4. DB SALE FUEL AMNT	4. Key in the fuel amount and press [ENTER] .
	5. DB SALE CONFIRM AMOUNT	5. Key in fuel amount again and press [ENTER] .
	6. FUEL GRADE 1=NNNNNNNN	6. Press the correct key from [1] to [5] to choose the proper fuel grade.
	7. DB SALE MISC AMNT	7. Key in amount of the non fuel transaction and press [ENTER] or press [ENTER] to bypass.
	8. DB SALE CUST ENTERS CASH BACK	8. Customer uses PIN pad.

PIN PAD DISPLAY	PIN PAD ACTION
9. CASH BACK AMOUNT	9. Customer keys in the cash back amount and presses [ENTER] on the PIN pad, simply presses [ENTER] on the PIN pad to bypass or [CLEAR] on PIN pad to re-enter amount.
10. TOTAL \$XX.XX IS THIS CORRECT?	10. Press [ENTER] for "Yes" or press [BACK SPACE] for "No".
11. WAITING FOR PIN	11. Please wait...

PIN PAD DISPLAY	PIN PAD ACTION
12. AMOUNT \$X.XX... ...PUSH ENTER	12. Customer keys in their PIN and then presses [ENTER] on the PIN pad.
13. WAITING...RECEIVING	13. Please wait...
14. DB SALE AP XXXXXX SEQ XXX	14. Please wait for the merchant receipt to print.
15. TEAR NOW, PRESS ENTER	15. Press [ENTER] to print custom receipt.

FUNCTION	DISPLAY MESSAGE	OPERATOR ACTION
VOID	1. SWIPE CARD FOR SALE	1. Press [VOID] key.
	2. INV SEQ PAN	2. Press the left [▲] key to select a transaction to void by invoice number, press the middle [▲] key to select by sequence number or the right [▲] key to select by entering the last 5 digits of the credit card number.
	2. VOID ENTER....	2. Key in either the invoice number, sequence number or last 5 digits of the credit card number and press [ENTER] .
	3. VOID INV OR SEQ XXX ? XXXXXXXXXXXX	3. Press [ENTER] to void or [CLEAR] to exit function.
	4. Void Item XXX Press ENTER TO CONFIRM!	4. Press [ENTER] to confirm void.
	5. SEQ# XXX UPDATED	5. Wait for the receipt to print...
6. TEAR NOW, PRESS ENTER	6. Press [ENTER] to print customer receipt.	

FUNCTION	DISPLAY MESSAGE	OPERATOR ACTION
RETURN	1. SWIPE FOR SALE	1. Press [RETURN] .
	2. CREDIT DEBIT	2. For credit return, press the left [▲] key.
	3. RETURN ENTER ACCOUNT #	3. Swipe card.
	4. CARD TYPE RETURN CARD TYPE TRANSACTION?	4. Press [ENTER] .
	5. CARD TYPE RETURN ENTER LAST 4 DIGITS	5. Key in the last four digits of the credit card number and press [ENTER] .
	6. XXXXXXXXXXXXX IS CARD # CORRECT?	6. If the displayed card number is correct, press [ENTER] , if not press [BACK SPACE] .
	7. CARD TYPE RETURN RETURN AMOUNT	7. Key in the return amount and press [ENTER] .
	8. CARD TYPE RETURN CONFIRM AMOUNT	8. Key in the return amount again and press [ENTER] .
	9. TOTAL \$XX.XX IS THIS CORRECT?	9. Press [ENTER] for "Yes" or press [BACK SPACE] for "No".
	10. CARD TYPE RETURN ACCEPTED SEQ XXX	10. Please wait for the merchant receipt to print.
	11. TEAR NOW, PRESS ENTER	11. Press [ENTER] to print custom receipt.

FUNCTION	DISPLAY MESSAGE	OPERATOR ACTION
AUTH ONLY	1. SWIPE CARD FOR SALE	1. Press [AUTH ONLY] key.
	2. AUTH ONLY ENTER ACCOUNT #	2. Swipe card.
	3. CARD TYPE AUTH ONLY CARD TYPE TRANSACTION?	3. Press [ENTER] .
	4. CARD TYPE AUTH ONLY ENTER LAST 4 DIGITS	4. Key in the last four digits of the credit card number and press [ENTER] .
	5. XXXXXXXXXXXXX IS CARD # CORRECT?	5. If the displayed card number is correct, press [ENTER] , if not press [BACK SPACE] .
	6. CARD TYPE AUTH ONLY ENTER TOTAL AMOUNT	6. Key in the amount and press [ENTER] or press [ENTER] to bypass.
	7. CARD TYPE AUTH ONLY CONFIRM AMOUNT	7. Key in the auth only amount again and press [ENTER] .
	8. TOTAL \$XX.XX IS THIS CORRECT?	8. Press [ENTER] for "Yes" or press [BACK SPACE] for "No".
	9. CARD TYPE AUTH ONLY AP XXXXXX	9. Please wait for the merchant receipt to print.
	10. TEAR NOW, PRESS ENTER	10. Press [ENTER] to print customer receipt.

FUNCTION	DISPLAY MESSAGE	OPERATOR ACTION
OFFLINE* (TICKET ONLY)	1. SWIPE CARD FOR SALE	1. Press [OFFLINE] key.
	2. OFFLINE MUST AUTHORIZE FIRST	2. Please wait...
	3. OFFLINE ENTER ACCOUNT #	3. Swipe card.
	4. CARD TYPE OFFLINE CARD TYPE TRANSACTION?	4. Press [ENTER] .
	5. CARD TYPE OFFLINE ENTER LAST 4 DIGITS	5. Key in the last four digits of the credit card number and press [ENTER] .
	6. XXXXXXXXXXXXX IS CARD # CORRECT?	6. If the displayed card number is correct, press [ENTER] , if not press [BACK SPACE] .
	7. CARD TYPE OFFLINE FUEL AMOUNT	7. Key in the fuel amount and press [ENTER] .
	8. CARD TYPE OFFLINE CONFIRM AMOUNT	8. Key in the amount again and press [ENTER] .
	9. FUEL GRADE 1=NNNNNNNN	9. Press the correct key from [1] to [5] to choose the proper fuel grade.
	10. CARD TYPE OFFLINE MISC AMNT	10. Key in amount of the non fuel transaction and press [ENTER] or press [ENTER] to bypass.
	11. TOTAL \$XX.XX IS THIS CORRECT?	11. Press [ENTER] for "Yes" or press [BACK SPACE] for "No".
	12. CARD TYPE OFFLINE AUTH CODE	12. Key in the previously obtained auth code and press [ENTER] .
	13. DIALING...CONNECTED	13. Please wait...
	14. CARD TYPE OFFLINE ACCEPTED SEQ XXX	14. Please wait for the merchant receipt to print.
	15. TEAR NOW, PRESS ENTER	15. Press [ENTER] to print customer receipt.

FUNCTION	DISPLAY MESSAGE	OPERATOR ACTION
CLOSE	1. SWIPE CARD FOR SALE	1. Press [CLOSE] key.
	2. SCANNING TRANS...	2. Please wait...
	3. PRINT REPORT? YES NO	3. Either press the left [▲] key to print the Batch Summary Report or right [▲] to bypass.
	4. DIALING...	4. Please wait...
	5. SETTLEMENT COMPLETE XXXXXXXXXXXX	5. Please wait for Batch Close Report to print, then press [CLEAR] .