

FUNCTION	DISPLAY MESSAGE	OPERATOR ACTION
INITIAL FUEL ENTRY TABLE (Please use to program fuel information after a full download.)	1. 1: \$0.000/G CHANGE DATA?	1. Press [ENTER] to program fuel grade 1 or press [BACK SPACE] to program next grade.
	2. GRADE 1 NAME: ENTER NEW TO CHANGE	2. Key in the grade name (using up to eight characters) and press [ENTER] .
	NOTE: To enter an alphabetic letter, press the [ALPHA] key twice then the key for that letter.	
	3. GRADE 1 PRICE/GAL: ENTER NEW TO CHANGE	3. Key in the grade 1 fuel price per unit (using up to six characters including the decimal) and press [ENTER] . To enter \$1.599, press [1] [VOID] [5] [9] [9] and press [ENTER] .
	NOTE: Minimum price per gallon allowed .1; Maximum price per gallon allowed 19.999.	
	4. 1: NNNNNNN \$X.XXX/G SAVE CHANGES?	4. Press [ENTER] to save the information or press [BACK SPACE] to re-enter information.
	5. 2: \$0.000/G CHANGE DATA?	5. Press [ENTER] to program fuel grade 2 or press [BACK SPACE] to program next grade.
	6. GRADE 2 NAME: ENTER NEW TO CHANGE	6. Key in the grade name (using up to eight characters) and press [ENTER] .
	NOTE: To enter an alphabetic letter, press the [ALPHA] key twice then the key for that letter.	
	7. GRADE 2 PRICE/GAL: ENTER NEW TO CHANGE	7. Key in the grade 2 fuel price per unit (using up to six characters including the decimal) and press [ENTER] . To enter \$1.699, press [1] [VOID] [6] [9] [9] and press [ENTER] .
	NOTE: Minimum price per gallon allowed .1; Maximum price per gallon allowed 19.999.	
	8. 2: NNNNNNN \$X.XXX/G SAVE CHANGES?	8. Press [ENTER] to save the information or press [BACK SPACE] to re-enter information.
	9. 3: \$0.000/G CHANGE DATA?	9. Press [ENTER] to program fuel grade 3 or press [BACK SPACE] to program next grade.
	10. GRADE 3 NAME: ENTER NEW TO CHANGE	10. Key in the grade name (using up to eight characters) and press [ENTER] .
	NOTE: To enter an alphabetic letter, press the [ALPHA] key twice then the key for that letter.	
	11. GRADE 3 PRICE/GAL: ENTER NEW TO CHANGE	11. Key in the grade 3 fuel price per unit (using up to six characters including the decimal) and press [ENTER] . To enter \$1.799, press [1] [VOID] [7] [9] [9] and press [ENTER] .
	NOTE: Minimum price per gallon allowed .1; Maximum price per gallon allowed 19.999.	
	12. 3: NNNNNNN \$X.XXX/G SAVE CHANGES?	12. Press [ENTER] to save the information or press [BACK SPACE] to re-enter information.
	13. 4: \$0.000/G CHANGE DATA?	13. Press [ENTER] to program fuel grade 4 or press [BACK SPACE] to program next grade.
	14. GRADE 4 NAME: ENTER NEW TO CHANGE	14. Key in the grade name (using up to eight characters) and press [ENTER] .
	NOTE: To enter an alphabetic letter, press the [ALPHA] key twice then the key for that letter.	
15. GRADE 4 PRICE/GAL: ENTER NEW TO CHANGE	15. Key in the grade 4 fuel price per unit (using up to six characters including the decimal) and press [ENTER] . To enter \$1.899, press [1] [VOID] [8] [9] [9] and press [ENTER] .	
NOTE: Minimum price per gallon allowed .1; Maximum price per gallon allowed 19.999.		
16. 4: NNNNNNN \$X.XXX SAVE CHANGES?	16. Press [ENTER] to save the information or press [BACK SPACE] to re-enter information.	
17. 5: \$0.000/G CHANGE DATA?	17. Press [ENTER] to program fuel grade 5 or press [BACK SPACE] to exit.	
18. GRADE 5 NAME: ENTER NEW TO CHANGE	18. Key in the grade name (using up to eight characters) and press [ENTER] .	
NOTE: To enter an alphabetic letter, press the [ALPHA] key twice then the key for that letter.		
19. GRADE 5 PRICE/GAL: ENTER NEW TO CHANGE	19. Key in the grade 5 fuel price per unit (using up to six characters including the decimal) and press [ENTER] . To enter \$1.999, press [1] [VOID] [9] [9] [9] and press [ENTER] .	
NOTE: Minimum price per gallon allowed .1; Maximum price per gallon allowed 19.999.		
20. 5: NNNNNNN \$X.XXX/G SAVE CHANGES?	20. Press [ENTER] to save the information or press [BACK SPACE] to re-enter information.	
21. PRINTING...	21. The terminal prints a fuel information report.	

FUNCTION	DISPLAY MESSAGE	OPERATOR ACTION
EDIT FUEL INFO	1. SWIPE CARD FOR SALE	1. Press the [#] key.
	2. LOCK MGMT SETUP	2. Press the right [▲] key.
	3. HOST LOCAL REVIEW	3. Press the middle [▲] key.
	4. DIAL PASS OPTIONS	4. Press the right [▲] key.
	5. PRINTER TIP OTHER	5. Press the right [▲] key.
	6. FUEL MISC	6. Press the left [▲] key.
	7. EDIT PRINT	7. Press the left [▲] key.
	8. 1: \$0.000/G CHANGE DATA?	8. Press [ENTER] to program fuel grade 1 or press [BACK SPACE] to program next grade.
	9. GRADE 1 NAME: ENTER NEW TO CHANGE	9. Key in the grade name (using up to eight characters) and press [ENTER].
	10. GRADE 1 PRICE/GAL: ENTER NEW TO CHANGE	10. Key in the grade 1 fuel price per unit (using up to six characters including the decimal) and press [ENTER]. To enter \$1.599, press [1] [VOID] [5] [9] [9] and press [ENTER].
	11. 1: NNNNNNN \$X.XXX/G SAVE CHANGES?	11. Press [ENTER] to save the information or press [BACK SPACE] to re-enter information.

NOTE: To enter an alphabetic letter, press the [ALPHA] key twice then the key for that letter.

NOTE: Minimum price per gallon allowed .1; Maximum price per gallon allowed 19.999.

NOTE: Repeat steps 8 through 11 or follow the procedures on the other side of this card to edit fuel grades 2 through 5.

ATTENTION: After editing the 5th grade, a terminal fuel report prints automatically.